


Pairing the Remote Control

To the Solar Siren



Press & Hold both Buttons
Wait to hear a Beep



To the Indoor Siren



Press & Hold both Buttons
Wait to hear a Beep

